

TUTTE LE CODIFICHE SONO IN INGLESE PER FACILITARNE LA COMPrensIONE ANCHE ALL'ESTERO. **(SEAT LEON KL)**
SIETE RESPONSABILI DI QUELLO CHE FATE ALLA VOSTRA AUTO. LE CODIFICHE LE HO TESTATE PERSONALMENTE SULLA MIA
LEON MY2021 CON SOFTWARE INFOTAIMENT 1672 ED IN COLLABORAZIONE CON CHI HA LA VERSIONE 17XX – 18XX - ALCUNE
CODIFICHE NON FUNZIONANO SULLA MY2020 – è richiesto lo sbocco del SFD per tutte le modifiche su centralina 09 – 5F - 17

LANE ASSIST WITH LANE CENTER SEAL, REMEMBER LAST SETTING AND DISABLE ERROR MESSAGE IF LANE ASSIST IS DISABLED

1/ Lane Assist Point Of Intervention: (Centraggio completo del lane assist)

- **Select Module A5 (Driver Assistance)**

- Select Long Coding
- Select Point Of Intervention
- Set To Early

2/ Lane Assist Warnings: (Disattiva segnale di allarme lane assist disattivato)

- **Select Module A5 (Driver Assistance)**

- Select Long Coding
- Select Lane Assist Off Text
- Change to Set To Disabled

3/ Lane Assist Settings: (Ricorda le impostazioni del Lane assist)

- **Select Module A5 (Driver Assistance)**

- Select Long Coding
- Select Configuration For Lane Departure Warning K15
- Set To Last Setting

EMERGENCY BRAKE SYSTEM (frenata di emergenza se non viene utilizzato il volante)

- **Select Module A5 (Driver Assistance)**

- Select Long Coding
- Select Emergency Assist
- Set To EA Variant 4

- **Select Control Unit 09**

- Select Adaptation
- Flashing (Lampeggio)
- Fahrerassistenz Blinkenfunktionen
- Set to Wechselblinken Warnblinken Bremsblinken
- Warnblinken durch Fahrerassistenz (se volete le 4 frecce)
- Set to Active
- Hupen durch Fahrerassistenz (se volete che suoni il clacson)
- Set to Active
- Travel Assist
- Set to Active
- Innenlicht durch_Fahrerassistenz (se volete accensione luci interne)
(questa voce non è sempre disponibile in questo adattamento)
- Set to Active

Alternativa

- Select Adaptation
- Interior light general setting
- Innenlicht durch_Fahrerassistenz
- Set to active

12 COLORS INSTEAD OF 10 (12 colori invece dei 10 impostati di serie (non il Viola))

- **Select Control Unit 09**

- Select Adaptation
- Interior light hmi config
- Hmi ambient color bitmask
- Hmi contour colors bitmask
- Hmi ambient colors fod bitmask
- Hmi contour colors fod bitmask
- **set all to 8B00FF**

CUPRA VIEWER (Aggiunge Vista Cupra al Cockpit)

Adding new views to cockpit - Cupra View on Leon FR

- **Select Control unit 17**

- Select Adaptation
 - Select View Activation
 - activate view 8
-

CUPRA STYLE (trasforma "tutto" nello style cupra - In Blu trovate le modifiche minime per avere potenza e coppia)
Adding Cupra Style car & Logo on display and infotainment

- Select Control Unit 17

- Select Long Coding
- Select Start Screen
- Select Version 2 (colore di avvio rame)
- Select Lap counter
- Set to Yes
- Select Vehicle variant
- Set to Derivative 6 (Selezionare questo se è una Sporturer non disponibile su my2020)
- Set to Derivative 4 (Selezionare questo se è una Hatchback non disponibile su my2020)
- Select Adaptation
- Select Configuration of displayable contents
- Select Engine power (necessario attivare Vehicle variant)
- Set to Active
- Select Engine torque (necessario attivare Vehicle variant)
- Set to Active
- Select G-meter
- Set to Active

- Select Multimedia 5F (questo solo per avere loghi Cupra Infotainment)

- Select Long coding
- Select Car Bodystyle addition
- Set to 1
- Select Vehicle type power stage 2
- Set to Yes
- Select Adaptation
- Select Function configuration hmi
- Select Skinning
- Set to 2
- Select Screenings
- Set to 1

(Attiva il lane assist "plus" che si comporta quasi come il travel assist e funziona sotto i 60km/h con ACC attivo)
THIS ACTIVATES A SORT OF TRAVEL ASSIST. TO WORK, **THE LANE ASSIST EARLY MUST ALSO BE CODED**
AND THE ACC MUST BE ACTIVE WITH THE SET SPEED. IT ALSO WORKS UNDER 60 KM/H.

- Select Module A5 (Driver Assistance)

- Select Long Coding
- Select HC Variant
- Set To Variant 1
- Select Point Of Intervention
- Set To Early

(attiva le luci diurne anche posteriori)

SCANDINAVIAN DRL

- Select Central Elettric 09

- Select Adaptation
- Select Daytime running lights
- Select Tagfahrlicht-Dauerfahrlicht aktiviert zusaetzlich standlicht
- Set To Active

(Con cambio automatico riapre le portiere se premete la P)

ONLY DSG - AUTOMATIC DOOR RELEASE WHEN THE P BUTTON IS PRESSED

- Select Central Elettric 09

- Select Adaptation
- Select Zv Autolock
- Select automatic unlock nar
- Set to Active

(disattiva la riaccensione del motore muovendo il volante)

DEACTIVATES ENGINE IGNITION WITH STEERING WHEEL MOVEMENT

- Select Module 44 (Sterring Assistance)

- Select Long Coding
 - Select Engine start through power steering
 - Set To Not active
-

(disattiva la riaccensione del motore quando l'auto davanti a voi riparte, lo farà solo su vs comando)
DEACTIVATES ENGINE IGNITION WITH VEHICLE MOVEMENT THAT BEFORE YOU. IF ACC IS ACTIVATED, THE MOTOR WILL RE-ACTIVATE DESPITE THIS SETTING

- **Select Module 13 (Adaptive Cruise Control)**

- Select Adaptation
 - Select Expanded restart function
 - Set To Off
-

(Beep di conferma accensione e spegnimento, solo per Allarme Volumetrico presente)
BEEP OF CONFIRMATION ON AND OFF. FOR VOLUMETRIC ALARM ONLY

- **Select Central Elettric 09**

- Select Adaptation
 - Select ZV Quittierungen
 - Select Quittungston hmi einstellbar
 - Set to Active
 - Select Quittierungston bei entriegeln
 - Set to Active
 - Select Quittungs ton bei verriegeln
 - Set to Active
-

(attiva flash dei fendi nebbia quando utilizzate il flash degli abbaglianti)
ACTIVATE FOG LIGHTS WITH HIGH BEAM FLASHING – NOT WORK ON CUPRA LEON

- **Select Central Elettric 09**

- Select Adaptation
 - Select LEUCHTE 12 NL L B45
 - Select Lichtfunktion C 12
 - Set to Lichthupe
 - Select LEUCHTE 13 NL R B5
 - Select Lichtfunktion C 13
 - Set to Lichthupe
-

ACTIVATE FOG LIGHTS WITH DRL LIGHT

(Questo se attivo va a coprire i flash con gli abbaglianti quando i DRL sono accesi quindi di giorno)

- **Select Central Elettric 09**

- Select Adaptation
 - Select LEUCHTE 12 NL L B45
 - Select Lichtfunktion E 12
 - Set to Tagfahrlicht
 - Select Dimmwert DEF 12
 - Set to 100
 - Select LEUCHTE 13 NL R B5
 - Select Lichtfunktion E 13
 - Set to Tagfahrlicht
 - Select Dimmwert DEF 13
 - Set to 100
-

FOG LIGHTS FLASHING TOGETHER WITH DIRECTIONAL ARROW

(Questo fa lampeggiare alla stessa velocità frecce e fendinebbia anche se avete i fendi abbinati ai DRL)

- **Select Central Elettric 09**

- Select Adaptation
 - Select LEUCHTE 12 NL L B45
 - Select Lichtfunktion D 12
 - Set to Blinken links Hellphase
 - Select Dimmwert DEF 12
 - Set to 100
 - Select LEUCHTE 13 NL R B5
 - Select Lichtfunktion D 13
 - Set to Blinken rechts Hellphase
 - Select Dimmwert DEF 13
 - Set to 100
-

(Attiva allarme con clacson, per chi non ha il volumetrico! Si attiva se vengono aperte le portiere a veicolo chiuso, tipo spaccando un vetro e aprendo la portiera)

ACTIVATE OEM ANTI THIEF ALARM WITH HORN AND DIRECTION INDICATORS

- Select Central Elettric 09

- Select Adaptation
 - Select Diebstahlschutz Schnittstelle
 - Select DWA verbaut
 - Set to installed
 - Select Diebstahlschutz.Modulsoftware
 - Select Akustischer Alarm ueber Hupe
 - Set to Active
 - Select Anti.theft blinkers by inter.door handle activ.
 - Set to On
 - Select DWA campermode
 - Set to Active
 - Select Dynamic turn signal control
 - Select Theft flashing
 - Set to active
-

TACHOMETER END VALUE (cambiare valore finale del tachimetro)

- Select Control Unit 17

- Select Adaptation
- Select tachometer end value

Set to:

- Version 0 = 260km/h
 - Version 1 = 300km/h
 - Version 2 = 240km/h
-

OVERTAKING RIGHT PREVENTION (disattivare prevenzione sorpasso a destra)

- Select Control Unit 13

- Select Long coding
 - Select overtaking_right_prevention
 - Set to Deactivated
-

AUTOLOCK DOOR MENU IN MMI (attivare e disattivare chiusura automatica porte tramite menu)

- Select Central Elettric 09

- Select Adaptation
 - Select ZV Autolock
 - Select ZV Autolock autounlock hmi
 - Set to Adjustable
-

AIRCARE MEMORY FUNCTION (memorizza l'ultima impostazione dell'aircare)

- Select Central Unit 08

- Select Adaptation
 - Select Filtering of interior air, store
 - Set to Active
-

AIR RECIRCULATION MEMORY FUNCTION (memorizza l'ultima impostazione del ricircolo aria)

- Select Central Unit 08

- Select Adaptation
 - Select Store recirculation air setting for terminal 15 off
 - Set to Save
-

ACTIVATION/DEACTIVATION AIR RECIRCULATION IN AUTO MODE (consente di attivare/disattivare il ricircolo aria senza disattivare la modalità AUTO del clima)

- Select Central Unit 08

- Select Adaptation
 - Select manuel_air_recirculation_deactivate_AUTO_mode
 - Set to Not activated
-

CRUISE CONTROL MODE (aggiunge la modalità cruise control classica, cioè non adattiva)

- Select Control Unit 13

- Select Long coding
 - Select Cruise_control_mode
 - Set to Activated
-

HIGH BEAM ASSIT MEMORY FUNCTION (memorizza l'ultima impostazione degli abbaglianti automatici)

- Select Central Elettric 09

- Select Adaptation
 - Select Fernlicht_assistent
 - Select Fernlichtassistent Reset
 - Set to Not Active
-

COMING/LEAVING HOME FUNCTION WITH FOG LIGHT (usa i fendinebbia come coming/leaving home)

- Select Central Elettric 09

- Select Adaptation
 - Select BPA function status
 - Select Coming home Leuchten
 - Set Fog Light
-

WINDOWS ALWAYS OPERABLE (finestrini funzionanti anche dopo lo spegnimento del quadro e con porte aperte)

- Select Central Elettric 09

- Select Adaptation
 - Select ZV Komfort Fensterheber
 - Select Freigabenachlauf_abbruch_bei_tueroeffnen
 - Set to Not Active
-

CLOSING DOORS VIA REMOTE KEY WITH ENGINE RUNNING (chiusura porte dal telecomando con motore acceso)

- Select Central Elettric 09

- Select Adaptation
- Select ZV Allgemein
- Select Funk bei Klemme 15 ein
- Set Active

Tutte le modifiche qui sopra descritte sono attivabili tramite la porta ODB che si trova sotto al volante a sinistra. Si deve acquistare OBDeleven con abbonamento PRO (circa 100€ di spesa). Fatelo solo se attirati da questo particolare mondo. Sappiate che le modifiche possono invalidare la garanzia del veicolo e smanettamenti casuali potrebbero disattivare funzioni utili. Quindi prima di fare qualsiasi modifica accertatevi di salvare lo stato attuale.

Per trovare le voci scritte in inglese è sufficiente andare in impostazioni dell'applicazione OBDeleven e posizionare la lingua inglese come primaria. Fate tutto con cognizione e attenzione.

Nelle centraline 13 e A5 non c'è protezione SFD quindi non serve lo sblocco, per la codifica bisogna prima inserire il codice 20103 nella voce "accesso di sicurezza" del menù corrispondente dell'unità.